

Akuvox


Akuvox EM63 User Manual

Content

1. Overview.....	3
1.1. Introduction.....	3
1.2. Features.....	4
2. Installation.....	5
2.1. Check package contents.....	5
2.2. Connection diagram.....	5
3. Configuration.....	6
3.1. Expansion module selection.....	8
3.2. Backlight Setting.....	8
3.3. Ext Key Configuration.....	10
4. Software update.....	14
5. Troubleshooting.....	15

1. Overview

1.1. Introduction



EM63 is an Expansion Module for Akuvox IP Phones, EM63 with large graphic LCD display. 22 programmable keys and 22 dual-color LEDs, and can be programmed to various features include BLF, BLF List, Speed Dial, Hot Desking, Record, XML Browser, Account, Call forward, Pickup, Intercom, DTMF, etc.

1.2. Features

➤ Highlights

- **4.3" 272x480 Color Graphical LCD with Backlight**
- **Powered by Akuvox IP Phone SP-R59P**
- **22 Keys and 22 dual-color LEDs**

➤ Features

- Different icons for each function
- Multi-Language Support
- Programmable keys for BLF, BLF List, Speed Dial, Hot Desking, Record, XML Browser, Account, Call forward, Pickup, Intercom, DTMF, etc
- Firmware Upgradable
- Powered by Akuvox IP phone SP-R59P

➤ Physical Features

- 22 physical keys each with a dual-color LED
- 4.3" 272x480 Graphical LCD with Backlight, 4-bit Graylevel
- 2 RJ12(6P6C) ports for data in and out
- AC Power Adapter: Input: AC 100-240V; Output: DC 5V/1A


2. Installation

2.1. Check package contents

Please refer to the package list below to check the completeness of package

Name	Quantity
EM63 unit	1
User Guide	1
RJ-12 Cable	1
Jointbar	1
Stand	1
Screws	4

2.2. Connection diagram




3. Configuration


The EM63 expansion module supports 20 DSS Ext keys. The only way to configure the Ext keys is to access to the web interface of the sip phone. To login the web interface, you should obtain the IP address of the IP phone in advance. Press the OK key when the phone is idle after connecting to the network, and the phone will display the IP address and some other status. Enter the IP address in the IE or other web browser on your PC, the default username and password are both admin and admin.

Note: Ensure EM63 is connected to IP phone successfully via the RJ12 cable.


- Press the OK key when the phone is idle after connecting to the network.



- Type the IP address : <http://192.168.10.4> on IE, input default User Name and Password: admin/admin to login the web interface.



- Go to the path: Phone->Ext Key to see the configuration of each Ext key. Allow user to assign specific feature to the designated Ext key. For Ext key, the available feature list: DND, Menu, MSG, Status, Book, Fwd, PickUp, Group PickUp, Intercom, Speed Dial, History, Favorites, Redial, Account, ACD, BLF, BLFList, Call Return, Hot Desking, Record, XML Browser, DTMF.




3.1. Expansion module selection

Several expansion modules can be chained together to connect to a SP-R59P IP phone, so that you can have many more Ext keys to use at the same time.

Up to six expansion modules can be daisy-chained to a single SP-R59P IP phone. Before configuring the Ext keys, you should choose the right expansion module first.

- Go to the path: Phone->Ext Key->Expansion Module;
- Choose the designated expansion module;
- Press Submit to accept the change.




3.2. Backlight Setting

Backlight level

Set the screen backlight level of the expansion module. There are five levels of the backlight intensity, default is level 3.


- Go to the path: Phone->Ext Key->Backlight Intensity;
- Choose the backlight level;
- Press Submit to accept the change.



Backlight Duration


Set the duration of backlight of the expansion module. Default value is 20s.

- Go to the path: Phone->Ext Key->Backlight Time;
- Choose the backlight time;
- Press Submit to accept the change.



3.3. Ext Key Configuration


- Go to the path: Phone->Ext Key->key;
- Choose the function of each Ext key in the drop-down menu;
- Fill in the value of each item: "Label"、"Value"、"Account"、"Extension" (Not all of items are necessary for each function);
- Press Submit to accept the change.



For Example:

DND

- Go to the path: Phone->Ext Key->key;
- Choose DND function of each Ext key in the drop-down menu;
- Fill in the value of Label, such as: Do not disturb;
- Press Submit to accept the change.



BLF(Busy Field Lamp)

- Go to the path: Phone->Ext Key->key;
- Choose BLF function of each Ext key in the drop-down menu;
- Fill in the value of each item, such as: Label->Pick up; Value->1005; Extension->*; Account->Account1;
- Press Submit to accept the change.

- ▶ Status
- ▶ Account
- ▶ Network
- ▼ Phone
 - Time/Lang
 - Preference
 - Call Feature
 - Voice
 - Key/Display
 - Ext Key**
 - Ringtones
 - Tones
 - Dial Plan
 - Action URL
- ▶ PhoneBook
- ▶ Upgrade
- ▶ Security

Ext Key

Upload

Firmware Version
 Expansion Module
 Backlight Intensity
 Backlight Time

Key	Type	Label	Value	Account	Extension
Key 1	BLF <input type="button" value="v"/>	pick up	1005	Account 1 <input type="button" value="v"/>	**
Key 2	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 3	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 4	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 5	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 6	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 7	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 8	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 9	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 10	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 11	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 12	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 13	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 14	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 15	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 16	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 17	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 18	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 19	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	
Key 20	N/A <input type="button" value="v"/>			Account 1 <input type="button" value="v"/>	

Help

Note :
 Max length of characters for input box:
 255: Broadsoft Phonebook server address
 127: Remote Phonebook URL & AUTOP Manual Update Server URL
 63: The rest of input boxes

Warning :

Field Description :

Submit Shortcut

4. Software update

To select an upgrade rom file from local side, then press Submit to access the upgrading.

Note: Please make sure it's in right file format for right model.

The screenshot shows the 'Ext Key' configuration page in the Akuvox web interface. The page has a blue header with the 'Akuvox' logo and a 'LogOut' link. A left sidebar contains a navigation menu with categories like Status, Account, Network, Phone, PhoneBook, Upgrade, and Security. The 'Ext Key' category is selected. The main content area is titled 'Ext Key' and contains several configuration options: 'Upload' (with a '浏览...' button and 'Submit'/'Cancel' buttons), 'Firmware Version' (dropdown), 'Expansion Module' (dropdown), 'Backlight Intensity' (dropdown), and 'Backlight Time' (dropdown). Below these is a table with 20 rows, each representing a key (Key 1 to Key 20). Each row has columns for 'Key', 'Type' (all 'N/A'), 'Label', 'Value', 'Account' (all 'Account 1'), and 'Extension'. At the bottom of the table are 'Submit' and 'Cancel' buttons. On the right side, there is a 'Help' section with a 'Note' (regarding character limits and server URLs), a 'Warning' section, and a 'Submit Shortcut' section with 'Submit' and 'Cancel' buttons.

5. Troubleshooting

Issue 1: The EM63 LCD is blank

- If more than two expansion modules are connected to a SP-R59P IP phone, ensure that at least one expansion module is plugged into a functional adapter.

Issue 2: The EM63 LCD is back

- Check the backlight level of expansion module on the web interface, choose a comfortable backlight level for usage.

Issue 3: Cannot access the web interface

- Check the connection between the PC port of the device and the network port of the computer. Make sure it is fine.
- Check whether the IP address of the device is correct.
- If it is LAN, please make sure there is no IP address collision with other devices on the network.

For more information about the configuration, please refer to SP-R59P IP Phone User Guide.